3P Robot

Other name - Three Prismatic joint Robot

DOF - 3

Denavit Hartenberg (DH) Parameter

Ti = Minimum number of Parameters to describe forward kinematics

= Roty, or, Transy, di, Transx, a.
Rotiz, di

where,

ai - link length. di - link twist di - link offset . Oi - Joint angle

Final DH matrix

forward kinematics

Joint 1

0=90° a;=0m d;=90° d;=0.3m

$$T_1 = \begin{bmatrix} 0 & 0 & 1 & 0 \\ 1 & 0 & 0 & 0 \\ 0 & 1 & 0 & 0.3 \\ 0 & 0 & 0 & 1 \end{bmatrix}$$

Here,

COS 90 = 0 Sin 90 = 1

$$T_{2} = \begin{bmatrix} 0 & 0 & -1 & 0 \\ -1 & 0 & 0 & -0.15 \\ 0 & 1 & 0 & 0.2 \\ 0 & 0 & 0 & 1 \end{bmatrix}$$

Here,

$$(0)(-90) = 0$$
 $(0)(90) = 0$
 $(0)(-90) = -1$ $(0)(90) = 1$

Joint 3

$$T_3 = \begin{bmatrix} 1 & 0 & 0 & 0.15 \\ 0 & 0 & -1 & 0 \\ 0 & 1 & 0 & 0.2 \\ 0 & 0 & 0 & 1 \end{bmatrix}$$


Here,

$$\cos 0 = 1$$
 $\cos 90 = 0$
 $\sin 0 = 0$ $\sin 90 = 1$

Forward kinematics of 3P robot after set on desired Position from origin Point

is verified on 66 Robo Analyzer of software


VERIFICATION



PROCEDURE VIDEO FOR ROBOANALYZER DEMO VIDEO

PROCEDURE

- 1. Open the RoboAnalyzer software.
- Select 3 on the select DOF dropdown list and also select 3P (3 PRISMATIC JOINT ROBOT) on the select robot dropdown list.
- 3. Press **FKin** button on the 3D model tab to simulate forward kinematics matrices for the final (or) desired position from origin position (or) point.



- 4. Then click Link Config tab to select **link 3** and change previous frame to **base frame**. Eventually press the **Update** button to get the **DH matrix** for 3P Robot.
- 5. Finally, I compared the software DH matrix with an observed DH matrix that I solved.

Joint 1

Joint 2

$$A_{2} = \begin{bmatrix} 0 & 0 & -(& 0 \\ -(& 0 & 0 & 0.15 \\ 0 & 1 & 0 & d_{2} \\ 0 & 0 & 0 & 1 \end{bmatrix}$$

Joint 3

$$A_3 = \begin{bmatrix} 1 & 0 & 0 & 0.15 \\ 0 & 0 & -1 & 0 \\ 0 & 1 & 0 & d_3 \\ 0 & 0 & 0 & 1 \end{bmatrix}$$

T= A, A2 A3

-0

Compare D4 D matrix to find d, d, d, d3

i) d2=0.2

 $(ii) - d_3 = -0.2$ $d_3 = 0.2$

 $d_{1}=0.3$

i. Thus above Parameters like didz, do are verified based on 66 Robo Analyser's software.